



If a vapor barrier is required, it must be applied prior to the bolt installation.

The threaded post must be set in approved epoxy and the epoxy fully cured prior to LM-60 application.

The threaded post must be mechanically abraded and primed w/E-5320 prior to sealant application.

Drilling through our neoprene membranes is not permitted.

The LM-60 must be applied by Gaco Western QA.

<b>Gaco Western</b> SINCE 1955			
TITLE <b>GacoFlex LM-60 - Bolt Penetration</b>			
SIZE <b>A4</b>	CAGE CODE	DWG NO <b>GW-LM-BP-01</b>	REV
6-16-2014	SCALE	Nils Nedrelid	SHEET