



If a vapor barrier is required, it must be applied prior to the bolt installation.

The torque nut must be fully torqued according to the manufacturer's instruction prior to sealant application.

The exp bolt must be mechanically abraded and primed w/E-5320 prior to sealant application.

Drilling through our neoprene membranes is not permitted.

The LM-60 must be applied by Gaco Western QA.

Gaco Western SINCE 1955			
TITLE GacoFlex LM-60 - Exp Bolt Penetration			
SIZE A4	CAGE CODE	DWG NO GW-LM-EBP-01	REV
6-24-2014	SCALE	Nils Nedrelid	SHEET